



# DJ PROMIXER



# MIDI IMPLEMENTATION



**STANTON DJC. 4  
AUDIO & MIDI IMPLEMENTATION**



**Installing your device** Your System must to recognize your Stanton DJC. 4 as Audio Device and MIDI Device before configure in DJ ProMixer.

**CONFIGURE YOUR AUDIO AND MIDI SETTINGS**

-----  
**IMPORTANT:** Install the drivers provided for the manufacturer and check the configuration of [this equivalent controller](#).  
 -----

### MIDI MAP (Overview)



### Detail



- 1.- PLAY/ PAUSE
- 2.- CUE
- 3.- MANUAL LOOP (1.- IN 2.- OUT – EXIT – RELOOP)
- 4.- AUTOLOOP FROM ¼ TO 32 BEATS (STARTS IN 4 BEATS) "Active" move "<<", "Del" move ">>"
- 5.- CUP (Cue and Play)
- 6.- KEYLOCK (BY DEFAULT DISABLED)
- 7.- EFFECTS DIRECT BUTTONS EFX 1, EFX2, EFX3
- 8.- MEMORY CUE / LOOP (1,2,3,4)
- 9.- SAMPLES (1,2,3,4)
- 10.- FX SYNC (FROM 2/1 TO 1/8 BEATS)
- 11.- FX DRY / WET
- 12.- FX PARAMETER
- 13.- ENABLE WHEEL VINYL MODE
- 14.- TRACKLIST SCROLL
- 15.- LOAD DECK (A AND B)
- 16.- BROWSER (PLAYLIST, GROUPS, EXPLORER), OPEN CLOSE FOLDERS
- 17.- PFL
- 18.- ROTARY KNOBS OF THE MIXER (GAIN, HI, MID,BASS)
- 19.- DECK'S VOLUMEN CONTROLS AND CROSSFADER
- 20.- PITCH
- 21.- SYNC
- 22.- BEND (WHEEL)
- 23.- BEND (BUTTONS)
- 24.- SCRATCH
- 25.- BRAKE

**More info about DJ ProMixer:**

<http://www.djpromixer.com>

**More info about mapping of Stanton DJC. 4**

<http://wp.me/p1NvxM-jk>